This is the entire tap assembly Kit for these models :

• Ascaso Dream boiler with thermoblock made after +11/2008

Ascaso Dream boiler group prior -10/2009

Kit 208 # 5601



Replacing the Tap kit:

This looks difficult to do, but it is very easy, you will need a spanner set and 10 min.

- 1. Plug out machine.
- 2. Make sure machine is cold before you do this
- 3. Remove top, unscrewing 2 long screws underneath, near the coffee group.
- 4. Remove steam tap knob using a screwdriver Fig.1
- 5. Remove boiler nut, holding Teflon pipe in place, using a spanner as shown Fig.2 Models vary
- 6. Finally fit kit starting with fitting the Teflon pipe to the new steam tap Fig.3 Insert brass bolt 1sr, then o ring on Teflon pipe, insert brass insert into Teflon pipe, insert pipe into steam pipe, tighten nut.
- 7. Repeat for the other end of the Teflon pipe and tighten.
- 8. After you have replaced the kit and pipe turn on machine to see if there any leaks, tighten nuts is this happens.
- 9. All ok put lid back on and make your self a coffee You earned it..!!



542. Kit 208



SPARE PARTS

Disclaimer: This intended as a guide only. We accept no responsibility for physical or personal damage.

If you feel that you may not be able to carry out the repair your self, contact a repair centre.

BLUS STAR COFFEE

www. Bluestarcoffee.eu





Remove 2 long screws to open the top of your coffee machine



Helpful tools:

You will need a spanner set, a Philips Screwdriver and a socket set, (depending on the tap kit)

